



Spare Parts List for TORPEDO 3-SPEED COASTER BRAKE S Type H 3111

| Ill. No. | Order No.    | Description   | Ill. No. | Order No.    | Description   |
|----------|--------------|---|----------|--------------|---|
| 1        | 0516 003 000 | Hexagonal nut FG 10,5                               | 27       | 0581 104 101 | Gear ring ass'y   |
|          |              | or  | 28       | 0312 003 000 | Circlip   |
| 1        | 0516 107 000 | Cap nut FG 10,5                                     | 29       | 0518 109 000 | Dog washer  |
| 2        | 0517 102 000 | Fixing plate (2 ea)                                 | 30       | 0581 104 100 | Gear ring   |
| 3        | 0516 001 300 | Lock nut FG 10,5 (3 ea)                             | 31       | 0533 111 100 | Clutch gear   |
| 4        | 0517 003 000 | Lock washer   | 32       | 0512 115 200 | Circlip   |
| 5        | 0515 004 104 | Cylinder screw M 5                                  | 33       | 0536 109 100 | Pawl (2 ea)   |
| 6        | 1626 ... ..  | Brake arm clip<br>(see special list<br>No. 191.6/2) | 34       | 0509 111 000 | Axle, length 154 mm   |
|          |              |   | 34       | 0509 112 000 | Axle, length 167 mm   |
| 7        | 0516 105 004 | Hexagonal nut M 5                                   | 35       | 0525 104 100 | Pressure spring   |
| 8        | 0519 014 300 | Brake lever   | 36       | 0525 013 200 | Pressure spring   |
| 9        | 0521 103 100 | Dust cap  | 37       | 0572 118 000 | Driver  |
| 10       | 0574 110 000 | Lever cone<br>(with dust cap and<br>brake lever)    | 38       | 0576 102 000 | Ball ass'y  |
|          |              |   | 39       | 0121 108 000 | Dust cap  |
| 11       | 0576 104 200 | Ball bearing (2 ea)                                 | 40       | 0521 108 000 | Cap   |
| 12       | 0573 103 100 | Brake cylinder                                      | 41       | 0508 105 000 | Fixed cone  |
| 13       | 0501 118 000 | Hub shell 36 holes                                  | 42       | 0121 109 000 | Dust cap  |
| 13       | 0501 118 001 | Hub shell 28 holes                                  | 43       | 0518 018 000 | Washer  |
| 14       | 0513 102 000 | Friction spring                                     | 44       | 1004 ... ..  | Sprocket 1/2 x 1/8"<br>push-on type (see<br>list No. 196.6/8) |
| 15       | 0574 106 000 | Braking cone ass'y                                  | 45       | 0512 011 000 | Circlip   |
| 16       | 0536 104 100 | Pawl (2 ea)   | 46       | 0516 100 100 | Chain guide nut   |
| 17       | 0512 102 100 | Circlip   | 47       | 0527 100 100 | Sliding block   |
| 18       | 0517 002 000 | Lock washer   | 48       | 0587 100 101 | Small pull rod  |
| 19       | 0518 103 000 | Thrust washer                                       | 49       | 0516 027 000 | Knurled nut   |
| 20       | 0512 104 000 | Circlip   | 50       | 0324 100 100 | Spanner   |
| 21       | 0534 103 000 | Locating sleeve                                     |          |              |   |
| 22       | 0572 119 000 | Planet wheel carrier<br>ass'y                       |          |              |   |
| 23       | 0518 106 000 | Thrust washer                                       |          |              |   |
| 24       | 0114 101 000 | Trunnion (3 ea)                                     |          |              |   |
| 25       | 0533 103 000 | Planet wheel (3 ea)                                 |          |              |   |
| 26       | 0502 112 000 | Planet wheel carrier                                |          |              |   |

www.torpedo-coasterbrake.com  
original parts and hubs  
assembly instructions  
trouble shooting